




INFINITI ESCL emulator


Description :

Device emulates Infiniti ESCL unit, compatible with all known native Infiniti ESCL units with 8-pin connector. Model years covered: 2005 and up (G series, F series etc.). Plug & Play.

Note that some later Infiniti vehicles use new Infiniti ESCL, must use new model ESCL emulator instead.

Installation on car:

Solder original connector onto board and attach wiring loom. That's all to do. Note that original SCL is powered ON only when there is a request for status or command for open or close.



LED on emulator board:

- Two blinks – ESCL is unlocking / unlocked state;
- One blink – ESCL is locking / locked state.